
## **Functions**






5401CK (F75)	5402CK (F76A)	5405CK (F86)
Passage or Closet Latch For doors that do not require locking. Either knob operates latchbolt at all times.	Privacy, Bedroom or Bath Lock For lavatory or other privacy doors. Either knob operates latchbolt unless outside knob is locked by push-button inside. Button automatically released when inside knob is turned or door is closed. A coin inserted and turned in emergency slot will unlock door from outside. Inside knob always active.	Storeroom or Closet Lock For use on storeroom, utility, exit doors. Deadlocking latchbolt. Latchbolt operated by knob inside, key in outside knob. Outside knob always rigid. Inside knob always active.
Outside Inside	Outside Inside	Outside Inside
5407CK (F109)	5408CK (F84)	5430CK (F87)
Entry Lock  For entrance, general home or office doors.  Deadlocking latchbolt.  Either knob operates latchbolt (except when outside knob is locked from inside).  Pushing turn button in inside knob locks	Classroom Lock For classroom or utility room doors. Deadlocking latchbolt. Either knob operates latchbolt (except when outside knob is locked by key). Inside knob is always active. Key releases outside knob.	Utility, Asylum or Institutional Lock Latchbolt operated by key in knob from either side. Deadlocking latchbolt. Both knobs always rigid.


- outside knob (automatically releases when inside knob is turned or key is rotated in locked outside knob).
- Outside knob may be retained in locked position by pushing and rotating turn button 90° clockwise to a horizontal position; not released until turn button is manually returned to the vertical position.
- Latchbolt is operated by key in outside knob or by rotating inside knob.
- Inside knob always active.





Outside

Inside



Outside Inside

## 5455CK

## **Dummy Trim**

• For non-operational knobs used for decorative trim.

