


INSTALLATION GUIDE

Door Seal, Head and Jamb Protection FS



How To Install:

- 1 Measure, cut, and install the head piece making contact with the door.
- Measure, cut, and install the side jambs. The jamb pieces should be continuos to the floor or top of the threshold. Mount pieces with the door in closed position. The seals should be set to hold a paper in place. This should be a contact seal, not crushing.

