






**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE



www.tmhardware.com

HAGER 9432-78" BARN DOOR SERIES

INSTALLATION GUIDE



To obtain the maximum weight capacity, all fasteners must be mounted securely into solid wood of studs or blocking within the wall or wood mounted to the face of the wall.






**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

www.tmhardware.com

HAGER 9432-78" BARN DOOR SERIES

INSTALLATION GUIDE








**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

www.tmhardware.com

HAGER 9432-78" BARN DOOR SERIES

INSTALLATION GUIDE



www.tmhardware.com



845-388-1300



845-388-1388



sales@tmhardware.com